

# Door sizes

## DOOR SIZES

	door size	multiple slabs used	unit width	rough opening		
TYPE A	1' 4" 16"		17 1/2"	18" x 83"	EXTERIOR	
	1' 6" 18"		19 1/2"	20" x 83"		
	1' 8" 20"		21 1/2"	22" x 83"		
	1' 10" 22"		23 1/2"	24" x 83"		
	2' 0" 24"		25 1/2"	26" x 83"		
	2' 2" 26"		27 1/2"	28" x 83"		
	2' 4" 28"		29 1/2"	30" x 83"		
	2' 6" 30"		31 1/2"	32" x 83"		
	2' 8" 32"		33 1/2"	34" x 83"		
	2' 10" 34"		35 1/2"	36" x 83"		
	3' 0" 36"		37 1/2"	38" x 83"		
	3' 0" 36"	(2) 1' 6"	37 1/2"	38" x 83"		INTERIOR
	3' 4" 40"	(2) 1' 8"	41 1/2"	42" x 83"		
	3' 8" 44"	(2) 1' 10"	45 1/2"	46" x 83"		
	4' 0" 48"	(2) 2' 0"	49 1/2"	50" x 83"		
	4' 4" 52"	(2) 2' 2"	53 1/2"	54" x 83"		
	4' 8" 56"	(2) 2' 4"	57 1/2"	58" x 83"		
	5' 0" 60"	(2) 2' 6"	61 1/2"	62" x 83"		
5' 4" 64"	(2) 2' 8"	65 1/2"	66" x 83"			
5' 8" 68"	(2) 2' 10"	69 1/2"	70" x 83"			
6' 0" 72"	(2) 3' 0"	73 1/2"	74" x 83"			
TYPE B	4' 0" 48"	(2) 2' 0"	49 3/4"	50 3/4" x 83"	EXTERIOR	
	4' 8" 56"	(2) 2' 4"	57 3/4"	58 3/4" x 83"		
	5' 0" 60"	(2) 2' 6"	61 3/4"	62 3/4" x 83"		
	5' 4" 64"	(2) 2' 8"	65 3/4"	66 3/4" x 83"		
	5' 8" 68"	(2) 2' 10"	69 3/4"	70 3/4" x 83"		
	6' 0" 72"	(2) 3' 0"	73 3/4"	74 3/4" x 83"		
TYPE C	3' 0" w/ (1) 12" sidelite		50 1/2"	51 1/2" x 83"	EXTERIOR	
	3' 0" w/ (1) 14" sidelite		52 1/2"	53 1/2" x 83"		
	5' 0"	(2) 2' 6"	62 1/4"	63 1/4" x 83"		
	5' 4"	(2) 2' 8"	66 1/4"	67 1/4" x 83"		
	5' 8"	(2) 2' 10"	70 1/4"	71 1/4" x 83"		
	6' 0"	(2) 3' 0"	74 1/4"	75 1/4" x 83"		
TYPE D	3' 0" w/ (2) 12" sidelites		63 1/2"	64 1/2" x 83"	EXTERIOR	
	3' 0" w/ (2) 14" sidelites		67 1/2"	68 1/2" x 83"		
	7' 6"	(3) 2' 6"	93 1/2"	94 1/2" x 83"		
	8' 0"	(3) 2' 8"	99 1/2"	100 1/2" x 83"		
	8' 6"	(3) 2' 10"	105 1/2"	106 1/2" x 83"		
	9' 0"	(3) 3' 0"	111 1/2"	112 1/2" x 83"		


## SWING

[ **method 1** ] **OPEN** the door and stand with your back against the door frame where the hinges are attached. Raise your arms sideways to form a "T" with your body. If your left hand is touching the door, the door is a left-hand swing. If your right hand is touching the door, the door is a right-hand swing.


[ **method 2** ] Stand facing the **CLOSED** door as if you are going to **PULL** it open. If the knob is on the left, the door is a left-hand swing. If the knob is on the right, the door is a right-hand swing.

## TYPE A


\*TOP VIEW



## TYPE B [ one full-time operable panel, one convertible panel ]



## TYPE C [ center-hinge double door sets with one fixed panel ]



## TYPE D [ exterior triple-door sets with two fixed panels ]

